


2015 National Interagency Aviation Frequency Guide



National Interagency Incident Communications Division
National Interagency Fire Center
3833 S. Development Ave.
Boise, Idaho 83705

Phone: (208)387-5644
FAX: (208)387-5892
E-mail: nifccdo@fs.fed.us

NATIONAL GEOGRAPHIC AREAS



NATIONAL INTERAGENCY AVIATION FREQUENCY GUIDE

FOR OFFICIAL USE ONLY

The Aviation Frequency Guide has been compiled by the National Interagency Communications Division (NIICD) / National Interagency Fire Center (NIFC) to support aviation communications within the Western United States. This guide lists the frequencies assigned to the Geographic Area Coordination Centers (GACCs) and interagency dispatch centers at the time of publication. Assigned frequencies and tones change. It is the responsibility of the user to obtain the correct frequency for their flight. Do not use any frequencies not assigned for use in your area.

An Interagency Aviation Technical Bulletin (IATB) dated Feb. 28, 2010 gives new direction in reference to toning the National Flight Following Frequency of 168.6500. Please read the IATB located in Appendix D. Should you have any questions regarding this change please contact the individuals listed at the bottom of the IATB.

Please report any errors, omissions or changes to the:

National Interagency Communications Division (NIICD)
National Interagency Fire Center (NIFC)
Attention: Mike Tuominen
3833 S. Development Ave.
Boise, Idaho 83705-5354

Telephone: (208) 387-5947
E-mail: mtuominen@fs.fed.us

FOR OFFICIAL USE ONLY

Editors Note: In the event that any reader of this Frequency Guide notices any omissions or errors, please contact your Regional Representative or the Editor at one of the numbers listed below:

<u>Editor:</u>	<u>Phone</u>	<u>E-mail</u>
Jose M. Lopez	(208) 387-5858	joselopez@fs.fed.us

<u>GACC Representatives:</u>	<u>Phone</u>	<u>E-mail</u>
<u>AICC, NWCC, SWCC, SACC</u> Mike Tuominen	(208) 387-5947	mtuominen@fs.fed.us

<u>EGBCC, WGBCC</u> Al Karnowski	(208) 387-5826	akarnowski@blm.gov
--	----------------	--

<u>NRCC, RMCC</u> Jose M. Lopez	(208) 387-5858	joselopez@fs.fed.us
---	----------------	--

<u>NoOps, SoOps, EACC</u> Gary Stewart	(208) 387-5718	gstewart@fs.fed.us
Communications Duty Officer (CDO)	(208) 387-5644	nifccdo@fs.fed.us

TABLE OF CONTENTS

<u>ALASKA GEOGRAPHIC AREA</u>	7
ALASKA BLM	8
STATE OF ALASKA DIVISION OF FORESTRY	9
<u>GREAT BASIN</u>	11
NEVADA	12
SOUTHERN IDAHO	14
UTAH	16
WESTERN WYOMING	18
<u>NORTHERN CALIFORNIA GEOGRAPHIC AREA</u>	19
<u>SOUTHERN CALIFORNIA GEOGRAPHIC AREA</u>	23
<u>NORTHERN ROCKIES GEOGRAPHIC AREA</u>	29
MONTANA	30
YELLOWSTONE NATIONAL PARK	34
NORTH DAKOTA	34
NORTHERN IDAHO	35
<u>NORTHWEST GEOGRAPHIC AREA</u>	37
OREGON	38
WASHINGTON	41
<u>ROCKY MOUNTAIN GEOGRAPHIC AREA</u>	43
COLORADO	44
SOUTH DAKOTA	47
WYOMING	47
<u>SOUTHERN GEOGRAPHIC AREA</u>	49
ARKANSAS/OKLAHOMA	50
FLORIDA	50
GEORGIA	50
KENTUCKY	51
LOUISIANA	51
NORTH CAROLINA	51
SOUTH CAROLINA	52
TENNESSEE	52
TEXAS	52
VIRGINIA	53
<u>SOUTHWEST GEOGRAPHIC AREA</u>	55
ARIZONA	56
NEW MEXICO	58

<u>APPENDIX A</u>	
TDFM-136/A COMMAND QUICK REFERENCE	63
<u>APPENDIX B</u>	
TDFM-136B COMMAND QUICK REFERENCE	67
<u>APPENDIX C</u>	
NPX-136D OPERATIONS SUMMARY	71
<u>APPENDIX D</u>	
NATIONAL FLIGHT FOLLOWING TONING	75

This page intentionally left blank.

ALASKA



**Alaska Interagency Coordination Center
1541 Gaffney Road
Ft. Wainwright, AK. 99703
Phone: (907) 356-5680
Fax: (907) 536-5678**

ALASKA BLM

Alaska Interagency Coordination Center

Ladd (Fort Wainwright)

64 50.25N / 147 36.87W

Phone: (907) 356-5681

Fax: (907) 356-5678

E-mail: akaccair@ak.blm.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	127.4500	127.4500	NA	N64 52.54/W148 3.82 (Ester Dome) N64 50.41/W147 36.28 (Fort Wainwright)
Air Guard	168.6250	168.6250	TX 110.9	N64 52.54/W148 3.82 (Ester Dome)

Galena Zone Dispatch Center

Edward G. Pitka Sr. Airfield (Galena)

Phone: (907) 656-1222

Fax: (907) 656-1702

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	127.4500	127.4500	NA	N64 44.17/W156 56.24 (Galena) N64 27/W157 17 (Totson Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N64 44.17/W156 56.24 (Galena)

Upper Yukon-Tanana Dispatch Center

Ladd (Fort Wainwright)

64 50.25N / 147 36.87W

Phone: (907) 356-5555

Fax: (907) 356-5556

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	127.4500	127.4500	NA	N64 52.54/W148 3.82 (Ester Dome) N66 54.84/W151 31.74 (Bettles) N66 34.29/W145 14.62 (Fort Yukon) N64 46.63/W141 9.48 (Eagle)
Air Guard	168.6250	168.6250	TX 110.9	N66 34.29/W145 14.62 (Fort Yukon)

ALASKA DIVISION OF FORESTRY

Delta Area Dispatch

P.O. Box 1149
Delta Junction, AK. 99737
64 03.34N / 145 44.07W
Phone: (907) 895-4225 or (907) 451-2301
Fax: (907) 895-4934
E-mail: dnr.dof.das.dispatch@alaska.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	132.4500	132.4500	NA	N64 3.34/W145 44.07 (Delta)

Fairbanks Area Dispatch

3700 Airport Way
Fairbanks, AK. 99709-4699
Phone: (907) 451-2623
Fax: (907) 451-2633
E-mail: dnr.dof.fai.dispatch@alaska.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	132.4500	132.4500	NA	N64 52.54/W148 3.82 (Ester Dome)

Kenai Interagency Dispatch Center

42499 Sterling Hwy
Soldotna, AK. 99669
Phone: (907) 260-4230
Fax: (907) 260-4205
E-mail: dnr.dof.kks.dispatch@alaska.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	132.4500	132.4500	NA	No location given
Ramp ATB OP	123.9750	123.9750	NA	N60 31.20/W150 58.80 (Kenai Tanker Base)

Matanuska-Susitna Area Dispatch Palmer Airbase

101 South Airport Road
Palmer, AK. 99645
Phone: (907) 761-6240
Fax: (907) 761-6228
E-mail: dnr.dof.paq.dispatch@alaska.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	132.4500	132.4500	NA	No location given
Ramp ATB OP	123.9750	123.9750	NA	N61 35.69/W149 5.32 (Palmer Airbase)

Southwest Area Dispatch

McGrath, AK

Phone: (907) 524-3367 / 3368

Fax: (907) 524-3932

E-mail: dnr.dof.mcg.dispatch@alaska.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	132.4500	132.4500	NA	N62 57.17/W155 36.34
Ramp ATB OP	123.9750	123.9750	NA	N62 57.17/W155 36.34 (McGrath Tanker Base)

State Logistics Center

3700 Airport Way

Fairbanks, AK. 99709-4699

Phone: (907) 451-2680

Fax: (907) 451-2763

E-mail: dnr.logistics@alaska.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	NA	NA	NA	N64 50.38/W147 49.53
<i>Note: Flight following is maintained by each area.</i>				

State Aviation: Steve Elwell, Aviation Supervisor

101 Airport Rd.

Palmer, AK. 99645

Phone: (907) 761-6271

Fax: (907) 761-6273

E-mail: Stephen.Elwell@alaska.gov**Tok Area Dispatch**

P.O. Box 10

Tok, AK. 99780

Phone: (907) 883-5134 or (907) 451-2302

Fax: (907) 883-5135

E-mail: dnr.dof.tas.dispatch@alaska.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	132.4500	132.4500	NA	N62 19.46/W142 59.80 (Tok)

Valdez - Copper River Area Dispatch

P.O. Box 185

Glennallen, AK. 99588


Phone: (907) 822-5534 or (907) 451-2789

Fax: (907) 822-8600

E-mail: dnr.dof.vcra.dispatch@alaska.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	132.4500	132.4500	NA	N62 2.00/W145 25.00 (Copper River)

GREAT BASIN



Great Basin Coordination Center
5416 Amelia Earhart Drive
Salt Lake City, UT 84116
Phone: (801)531-5320
Fax: (801) 531-5321

NEVADA

Central Nevada Interagency Dispatch Center

6330 W Jays Rd.
Winnemucca, NV 89445
Phone: (775) 623-1555
Fax: (775) 623-1754
Email: nellswor@blm.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	N40 50.61/W117 36.91 (Sonoma)
Local Contact	172.5750	166.7250	RX 103.5 TX 203.5	N41 00.52/W117 46.23 (Winnemucca Mountain)
Local Flight Following (Battle Mountain District)	169.0875	169.0875	RX/TX 114.8	N40 50.61/W117 36.91 (Sonoma)
Local Contact	171.7250	164.8375	TX 110.9	N38 30.11/W117 13.57 (South Booker) N40 20.21/W116 51.71 (North Mount Lewis)

Note: Central Nevada provides dispatch support for Winnemucca and Battle Mtn. Field Offices.

Elko Interagency Dispatch Center

725 Aspen Way
Elko, NV 89801
Phone: (775) 748-4000
Fax: (775) 748-4015
Email: smcintos@blm.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	N40 49.998/W115 47.254 (Elko)
Local Contact (Elko BLM)	171.5375	171.5375	TX 110.9	N40 53.42/W115 37.48 (Elko Mountain)
Local Flight Following	172.7500	172.7500	RX/TX 123.0	No location given

Ely Interagency Communications Center

702 N Industrial Way
 HC 33 Box 33500
 Ely, NV 89031-9408
 Phone: (775) 289-1925
 Fax: (775) 289-1930

Email: m4anders@nv.blm.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	N39 17.65/W114 50.16 (Ely)
Local Contact	169.7750	169.7750	NA	N36 12.6/W115 12.4 (Kimberly Mountain)

Las Vegas Interagency Communications Center

2980 North Rancho
 North Las Vegas, NV 89030
 Phone: (702) 515-5300
 Fax: (702) 646-1996

Email: fwaterman@blm.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	N36 12.6/W115 12.4 (Las Vegas)
Local Contact	169.4000	169.4000	NA	N36 19.04/W115 34.51 (Angel)

Sierra Front Interagency Dispatch Center

2311 Firebrand Circle
 Minden, NV 89423
 Phone: (775) 883-5995
 Fax: (775) 782-1441

Email: k1gonzal@blm.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N39 00.6/W119 45.50 (McClellan)
Air Guard	168.6250	168.6250	TX 110.9	N39 18.63/W119 53.1 (Slide Mountain)
Local Contact (Elko BLM)	169.9875	169.9875	TX 146.2	N39 15.43/W119 42.68 (McClellan Peak)
Local Flight Following	168.4250	168.4250	TX 114.8	No location given

SOUTHERN IDAHO

Boise Interagency Dispatch Center

3948 Development Avenue

Boise, ID 83705

Phone: (208) 384-3398

Fax: (208) 334-3404

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N43 36.18/W116 3.38 (Shaw Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N43 57.35/W115 41.11 (Pilot Peak)
Local Contact	122.9250	122.9250	NA	N43 16.18/W116 5.20 (Shafer Butte)
Local Flight Following	173.7625	173.7625	TX 110.9	N43 16.18/W116 5.20 (Shafer Butte)

Central Idaho Interagency Dispatch Center

1206 South Challis St.

Salmon, ID 83467

Phone: (208) 756-5157

Fax: (208) 756-5426

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	172.2750	172.2750	NA	N45 9.3/W114 0.22 (Baldy)
Local Flight Following (Central Idaho Direct)	170.1250	170.1250	NA	N45 9.3/W114 0.22 (Baldy)
Local Flight Following (Central Idaho)	170.1250	164.9375	TX 123.0	N44 20.48/W114 34.27 (Long Tom)
Local Flight Following (Central Idaho)	170.1250	164.9375	TX 110.9	N44 55.9/W114 39.6 (Middle Fork)
Local Flight Following (Central Idaho)	170.1250	164.9375	TX 103.5	N44 35.6/W114 28.5 (Twin Peaks)
Local Flight Following (Central Idaho)	170.1250	164.9375	TX 167.9	N44 40.4/W115 12.9 (Walker)

Eastern Idaho Interagency Dispatch Center

1405 Hollipark Drive
 Idaho Falls, ID 83401
 Phone: (208) 524-7600
 24 Hr.: (208) 529-1020
 Fax: (208) 524-7614

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N43 24.06/W113 1.37 (Big South Butte)
Air Guard	168.6250	168.6250	TX 110.9	N43 42 26/W111 20 37 (Garns)
Local Contact (BLM)	167.7750	163.1750	TX 114.8	N43 24.06/W113 1.37 (Big South Butte)

Payette Interagency Dispatch Center

605 S. Mission St.
 McCall, ID 83638
 Phone: (208) 634-2757
 Fax: (208) 634-5782

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N44 53.7/W116 6.0 (McCall)
Air Guard	168.6250	168.6250	TX 110.9	N45 0.1/W116 7.8 (Brundage Mountain)
Local Contact	121.7250	121.7250	NA	N45 0.1/W116 7.8 (Brundage Mountain)

South Central Idaho Interagency Dispatch Center

213 West F
 Shoshone, ID 83352
 Phone: (208) 886-2373
 Fax: (208) 732-7316

E-mail: BLM_ID_TF_SCIIDC@BLM.GOV

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N42 18.93/W113 39.88 (Mount Harrison)
Air Guard	168.6250	168.6250	TX 110.9	N42 18.93/W113 39.88 (Mount Harrison)
Local Contact (BLM)	166.8500	166.8500	NA	N42 53.08/W114 26.03 (Notch Butte)
Local Flight Following (Bennett)	170.1000	164.8000	TX 100.0	N43 15.00/W115 26.00 (Bennett Mountain)
Local Flight Following (Harrison)	170.1000	164.8000	TX 107.2	N42 18.93/W113 39.88 (Mount Harrison)
Local Flight Following (Big Peak)	170.1000	164.8000	TX 146.2	N43 40.10/W114 43.60 (Big Peak)

UTAH

Color Country Interagency Fire Center
 1770 West Kitty Hawk Drive
 Cedar City, UT 84720
 Phone: (435) 865-4600
 Fax: (435) 865-4691

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N37 35.51/W112 51.88 (Blowhard)
Air Guard	168.6250	168.6250	TX 110.9	N37 35.51/W112 51.88 (Blowhard)
Local Contact	171.5500	172.3500	TX 103.5	N37 35.51/W112 51.88 (Blowhard)
Local Flight Following (Color Country)	168.5000	168.5000	TX 123.0	N37 35.51/W112 51.88 (Blowhard) N36 47.5/W113 45.1 (Black Rock)

Moab Interagency Fire Center
 885 S Sand Flats Rd.
 Moab, UT 84532
 Phone: (435) 259-1850
 Fax: (435) 259-1860

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact (BLM)	172.7750	165.1750	TX 100.0	N38 31.67/W109 18.79 (Bald Mesa)

Northern Utah Interagency Fire Center
 14324 Pony Express Rd.
 Draper, UT 84020
 Phone: (801) 495-7600
 Fax: (801) 495-7611

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N41 12.0/W111 56.44 (Mount Ogden)
Air Guard	168.6250	168.6250	TX 110.9	N40 39.58/W112 12.10 (Farnsworth Peak)
Local Flight Following	168.5000	168.5000	NA	N41 12.0/W111 56.44 (Mount Ogden)

Richfield Interagency Fire Center

1830 S Industrial Park Rd.

Richfield, UT 84701

Phone: (435) 896-8404

Fax: (435) 896-4521

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N38 52.24/W112 14.21 (White Pine)
Air Guard	168.6250	168.6250	TX 110.9	N38 32.50/W112 4.38 (Monroe Peak)
Local Contact	172.250	169.1750	TX 110.9	N38 52.24/W112 14.21 (White Pine)

Uinta Basin Interagency Fire Center

355 North Vernal Avenue

Vernal, UT 84708

Phone: (435) 789-7021

Fax: (435) 781-9795

E-mail: cnelsen@fs.fed.us

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	172.2250	164.8000	TX 136.5	N40 44.53/W109 29.27 (East Park)
Local Contact (Forest Service)	172.2250	164.8000	TX 167.9	N40 21.30/W110 47.92 (Tabby Mountain)
Local Contact (BLM)	169.8125	162.1625	TX 136.5	N40 21.30/W110 47.92 (Tabby Mountain)
Local Contact	172.6250	164.9500	TX 123.0	N40 21 17.48/W109 08 49.20 (Blue Mountain)

WESTERN WYOMING

Teton Interagency Dispatch Center

PO Drawer 170

Moose, WY 83012


Phone: (307) 739-3630

Fax: (307) 739-3304

E-mail: grte_dispatch@nps.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following North	168.6500	168.6500	TX 110.9	N43 49.68/W110 20.11 (Rosie's Ridge)
Flight Following South	168.6500	168.6500	TX 110.9	N42 32.30/W110 6.59 (Big Piney)
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact (USFS)	171.3875	164.1375	TX 167.9	No location given

CALIFORNIA NORTH OPS



Northern California Coordination Center
6101 Airport Road
Redding, CA. 96002
Phone: (530) 226-2800
Fax: (530) 226-2742

NORTHERN CALIFORNIA

Camino Interagency ECC

2840 Mt. Danaher Road

Camino, CA 95709

Phone: (530) 642-5170

Fax: (530) 647-5279

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N38 44.29/W120 39.59 (Camino)
Air Guard	168.6250	168.6250	TX 110.9	N38 44.29/W120 39.59 (Camino) N38 55.89/W119 58.34 (South Lake Tahoe)
Local Contact Forest Net	171.5250	169.9500	TX 136.5	N38 42.16/W120 43.38 (Big Hill)

Fortuna Interagency ECC

118 Fortuna Blvd.

Fortuna, CA. 95540

Phone: (707) 726-1266

Fax: (707) 726-1265

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Admin Net	168.1250	168.1250	NA	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact Forest Net	168.7250	168.7250	NA	N40 52.436/W123 43.983 (Horse Mountain)

Grass Valley Interagency ECC

13120 Loma Rica Drive

Grass Valley, CA 95945

Phone: (530) 477-7237

Fax: (530) 477-5203

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.7750	170.5750	TX 146.2	N39 23.0/W120 36.8 (Grouse Ridge)
Air Guard	168.6250	168.6250	TX 110.9	N39 26.06/W122 41.48 (St. Johns Mountain)
Local Contact	168.7750	170.5750	TX 146.2	N39 23.0/W120 36.8 (Grouse Ridge)

Mendocino Interagency ECC

825 N. Humboldt Ave
 Willows, CA 95988
 Phone: (530) 934-7758
 Fax: (530) 934-2326

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	169.1750	169.9750	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	169.1750	169.9750	TX 110.9	N39 26.0/W122 41.60 (St. John Mountain)

Modoc Interagency ECC

225 West 8th Street
 Alturas, CA 96101
 Phone: (530) 233-8880
 Fax: (530) 233-8889

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.7500	168.7500	TX 110.9	N34 27.79/W120 7.68 (Grouse Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N41 24.95/W121 6.49 (Happy Camp)
Local Contact	170.7375	164.9875	TX 110.9	N34 27.79/W120 7.68 (Grouse Mountain)

Northern California Geographical Area Coordination Center

6101 Airport Rd.
 Redding, CA. 96002
 Phone: (530) 226-2800
 Fax: (530) 222-5489

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N40 39.69/W123 13.30 (Hayfork Bailey)
Air Guard	168.6250	168.6250	TX 110.9	N40 33.5/W122 46.6
Aircraft Ramp	122.9750	122.9750	NA	Ramp

Plumas National Forest ECC

159 Lawrence St
 Quincy, CA 95971
 Phone: (530) 283-7837
 Fax: (530) 283-7851

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N40 2.12/W121 11.6 (Red Hill)
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	170.5500	170.5500	TX 156.7	N40 2.40/W120 53.7 (Mount Hough)

Shasta-Trinity Interagency ECC

875 Cypress St.
 Redding, CA. 96001
 Phone: (530) 242-2400
 Fax: (530) 241-4807

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact Forest Net	171.5750	169.1000	TX 167.9	No location given
Local Contact CAL Fire	151.1600	159.2700	TX 136.5	N40 33.5/W122 46.60 (Bully Choop)

Susanville Interagency Fire Center

2550 Riverside Dr.
 Susanville, CA. 96130
 Phone: (530) 257-5575
 Fax: (530) 257-7149

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact Forest Net	172.2250	172.2250	NA	N40 19.1/W120 57.30 (Hamilton Mountain)
Local Contact BLM Fire Net	171.6250	171.6250	TX 136.5	No location given

Yreka Interagency ECC

1809 Fairlane Rd.
 Yreka, CA. 96097
 Phone: (530) 842-3380
 Fax: (530) 842-6953

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	164.1750	164.1750	NA	N41 44.1/W122 46.30 (Gunsight)
Air Guard	168.6250	168.6250	TX 110.9	N41 36.20/W122 38.30 (Antelope)
Local Contact Forest Net	164.1750	164.1750	NA	N41 44.1/W122 46.30 (Gunsight)

*Note: **All NOPS Federal ECC are equipped with National Flight Following 168.650 RX/TX T:110.9*

CALIFORNIA SOUTH OPS



Southern California Coordination Center
2524 Mulberry St.
Riverside, CA. 92501
Phone: (951) 276-6725
Fax: (909) 782-4900

SOUTHERN CALIFORNIA

Angeles Interagency ECC (ANF)

4503 W. William Barnes Ave.

Lancaster, CA 93536

Phone: (661) 723-3620

Fax: (661) 723-2710

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	172.3750	172.3750	TX 103.8	N34 46.5/W118 58.1 (Frazier Mountain)
Flight Following	168.6500	168.6500	TX 110.9	N34 20.2/W117 56.2 (Mount Waterman)
Air Guard	168.6250	168.6250	TX 110.9	N34 20.2/W117 56.2 (Mount Waterman)
Local Contact	172.3750	172.3750	TX 103.8	N34 46.5/W118 58.1 (Frazier Mountain)

Central California Interagency CC (SQF)

2750 Yowlumne Ave. Ste. B

Porterville, CA 93257

Phone: (559) 781-5780

Fax: (559) 781-3320

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N35 27.1/W118 34.9 (Breckenridge)
Flight Following	168.6750	168.6750	TX 103.5	N36 11.0/W118 35.8 (Jordan Peak)
Air Guard	168.6250	168.6250	TX 110.9	N35 42.7/W118 33.7 (Shirley Peak)
Local Contact	168.6750	168.6750	TX 103.5	N36 11.0/W118 35.8 (Jordan Peak)

Federal Interagency ECC (BDF)

602 S. Tippecanoe Ave.

San Bernardino, CA 92408

Phone: (909) 383-5651

Fax: (909) 383-5587

Email: FICC@fs.fed.us

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	171.4750	171.4750	TX 103.5	N34 6.57/W117 17.90 (San Bernardino)
Air Guard	168.6250	168.6250	TX 110.9	N34 6.57/W117 17.90 (San Bernardino)
Local Contact Forest Net	171.4750	171.4750	TX 103.5	N34 6.57/W117 17.90 (San Bernardino)

Los Padres Command Center (LPF)

3960 Mitchell Road

Santa Maria, CA 93455

Phone: (805) 961-5727

Commercial Phone: (805) 938-9142 Ext. 0

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	170.5500	170.5500	NA	N34 31.63/W119 58.68 (Santa Ynez Peak)
Air Guard	168.6250	168.6250	TX 110.9	N34 31.63/W119 58.68 (Santa Ynez Peak)
Local Contact	171.5500	171.5500	NA	N34 31.63/W119 58.68 (Santa Ynez Peak)
Forest Net	170.46250	170.4625	**	See Table Below
Admin Net	171.5500	171.5500	**	See Note Below

Los Padres Tone Selection Table					
Tone #	Tone	Location	Tone #	Tone	Location
1	110.9	Fraizer	9	100.0	Tassajera Peak
2	123.0	Sisar	10	107.2	Chews Ridge
3	131.8	La Cumbre	11	114.8	Plowshare
4	136.5	Alder Peak	12	127.3	Tepusquet
5	146.2	Black Mountain	13	141.3	Anderson
6	156.7	Torrey hill	14	151.4	Figueroa
7	167.9	Mount Pinos	15	162.2	Piedras Blancas
7	167.9	Santa Ynez Direct	16	192.8	Mount Diablo (SCI)
8	103.5	Cone Peak			

Monte Vista Interagency ECC (CNF)

2249 Jamacha Road

El Cajon, CA 92019-4301

Phone: (619) 557-5262

Fax: (619) 557-6935

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following North	168.6500	168.6500	NA	N33 42.67/W117 31.95 (Santiago Peak)
Air Guard	168.6250	168.6250	TX 110.9	N33 42.67/W117 31.95 (Santiago Peak)

Owens Valley Interagency ECC (INF)

351 Pacu Lane
 Bishop, CA 93514
 Phone: (760) 873-2488
 Fax: (760) 873-2459

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following INF North (Tone 3)**	168.1250	173.8000	TX 131.8	N37 46.5/W118 42.5 (Glass Mountain)
Flight Following INF North (Tone 8)	168.1250	173.8000	TX 103.5	N37 24.7/W118 11.2 (Silver Peak)
Flight Following INF South (Tone 4)**	168.7250	173.8375	TX 136.5	N36 58.6/W118 7.1 (Masourka)
Flight Following INF South (Tone 6)	168.7250	173.8375	TX 156.7	N36 16.0/W118 7.1 (Olancha)
Air Guard	168.6250	168.6250	TX 110.9	N37 24.7/W118 11.2 (Silver Peak)
Local Contact INF North (Tone 3)**	168.1250	173.8000	TX 131.8	N37 46.5/W118 42.5 (Glass Mountain)
Local Contact INF North (Tone 8)	168.1250	173.8000	TX 103.5	N37 24.7/W118 11.2 (Silver Peak)
Local Contact INF South (Tone 4)**	168.7250	173.8375	TX 136.5	N36 58.6/W118 7.1 (Mazourka)
Local Contact INF South (Tone 6)	168.7250	173.8375	TX 156.7	N36 16.0/W118 7.1 (Olancha)
<i>Note: Although the Inyo National Forest is equipped with the standard National Flight Following frequency, it is very limited in range and is unreliable for primary use. All resources flight following with Inyo National Forest must do so using the Inyo N.F.'s local frequencies, "INF North" (North of Bishop) or "INF South" (South of Bishop) as shown above. Primary tones/repeater sites are noted with ** above.</i>				

Sierra National Forest (SNF) Emergency Command Center

2311 N. Clovis Ave
 Fresno, CA. 93727
 Phone: (559) 348-1515
 Fax: (559) 348-0239

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N37 32.07/W120 1.82 (Bullion)
Air Guard	168.6250	168.6250	TX 110.9	N37 32.07/W120 1.82 (Bullion)
Fresno Air Base	123.9750	123.9750	NA	No location given
Local Contact	172.2250	169.9250	TX 146.2	N37 20.98/W119 25.68 (Shuteye)

Southern California Geographic Area (OSC)

2524 Mulberry Street
Riverside, CA 92501
Phone: (951) 276-6721
Fax: (915) 782-4900

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6250	168.6250	TX 110.9	N33 59.83/W117 22.16 (Riverside)
Air Guard	168.6250	168.6250	TX 110.9	N33 59.83/W117 22.16 (Riverside)


Stanislaus Emergency Command Center (STF)

19777 Greenley Road
Sonora, CA 95370
Phone: (209) 532-3786
Fax: (209) 533-1892
E-mail: stf_dispatch@fs.fed.us

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	170.5000	170.5000	TX 110.9	N38 8.395/W120 5.681 (Bald Mountain Helibase)
Air Guard	168.6250	168.6250	TX 110.9	N38.0665/W120.248 (Mount Elizabeth)
Local Contact OPS Net	168.7500	170.5000	TX 110.9	N38.038/W120.1619 (Mount Lewis, Tone-1)
Local Contact OPS Net	168.7500	170.5000	TX 167.9	N37.9703/W120.121 (Duckwall, Tone-7)

This page intentionally left blank.

NORTHERN ROCKIES



**Northern Rockies Coordination Center
Aerial Fire Depot
5765 West Broadway Missoula, MT. 59808-9361
Phone: (406) 329-4880
FAX: (406) 329-4891
Flight Following#: (800) 247-8328**

MONTANA

Billings Interagency Dispatch Center

1299 Rimtop
Billings, MT 59105
Phone: (406) 896-2900
888-BLM-FIRE
888-256-3473

Aircraft Desk: (406) 896-2906
Fax: (406) 896-2950

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N45 48.50/W108 32.68 (Billings, MT)
Air Guard	168.6250	168.6250	TX 110.9	N45 48.50/W108 32.68 (Billings, MT)
"Billings Dispatch Center"	171.1625	166.0875	TX 136.5	N45 10.6/W109 20.9 (Grizzly BLM)
<i>Crow Agency</i>				

Bitterroot Dispatch Center

533 Airport Road
Hamilton, MT 59840
Phone: (406) 363-7133
Fax: (406) 363-7131

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	169.6250	169.6250	TX 146.2	N46 1.5./W114 3.3 (Deer Mountain)
Air Guard	168.6250	168.6250		(Hamilton)
Local Contact Hamilton Dispatch North	169.6250	169.6250	TX 146.2	N46 1.5./W114 3.3 (Deer Mountain)
Local Contact Hamilton Dispatch South	168.7500	168.7500	TX 131.8	N46 1.5./W114 3.3 (Deer Mountain)

Note: BRC monitors National Flight Following but has limited response capability.

Note: North includes Stevensville, Darby and Sula districts. South includes West Fork District.

Bozeman Interagency Dispatch Center

Box 130, Federal Building
Bozeman, MT 59771
Phone: 406-587-6719
Fax: 406-587-6977

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N44 25.36/W111 12.22 (Garnet Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N45 13.33/W111 7.35 (Eaglehead Mountain)
Local Contact "Bozeman Dispatch"	164.8250	169.9250	TX 103.5	N45 49.03/W110 54.33 (Bridger West Repeater)
Local Contact "Bozeman Dispatch"	171.5500	164.1250	TX 123.0	N45 13.33/W111 7.35 (Eaglehead East Repeater)

Dillon Interagency Dispatch Center

420 Barrett Street
Dillon, MT 59725
Phone: (406) 683-3975
Fax: (406) 683-3925

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact North	171.0000	171.0000	TX 141.3	No location given
Local Contact South	171.4250	171.4250	TX 131.8	N45 12.305/W112 38.536 (Dillon)

Note: DDC monitors National Flight Following but has limited response capability.

Great Falls Interagency Dispatch Center

1101 15th Street North
Great Falls, MT 59401
Phone: (406) 731-5300
Fax: (406) 731-5301

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	N47 27.30/W111 23.24 (Gore Hill)
Local Contact "Great Falls Dispatch"	171.5000	171.5000	TX 123.0	N47 31.10/W111 16.80 (East of I-15)
Local Contact "Great Falls Dispatch"	171.7000	171.7000	TX 123.0	N47 31.10/W111 16.80 (West of I-15)

Helena Interagency Dispatch Center

8001D N Montana Ave
Helena, MT 59602
Phone: (406) 449-5475
Fax: (406) 457-0764
24 Hr: (406) 444-4242

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following**	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact "Helena Fire Desk"	166.2250	164.1500	TX 103.5	N46 49.73/W111 42.93 (Hogback Mountain)

*Note: **The Helena Fire Desk has spotty National Flight Following coverage outside of the Helena Valley.
Try Hogback if unable to reach dispatch.***

Kalispell Interagency Dispatch Center

650 Wolfpack Way
 Kalispell, MT 59901
 Phone: (406) 758-5260
 Fax: (406) 758-5393

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	NA	No location given
Local Flight Following "Kalispell Dispatch"	122.9250	122.9250	NA	No location given
Local Contact "Kalispell Disptach"	164.3750	164.3750	NA	N48 30.37/W114 20.83 (Big Mountain)
DNRC Blacktail Rptr "Kalispell Disptach"	151.1750	151.4750	TX 192.8	N48 30.37/W114 20.83 (Big Mountain)
<i>Note: National Flight Follow 168.6500 RX/TX T: 110.9 is monitored as a secondary flight following frequency.</i>				

Kootenai Interagency Dispatch Center

31374 US Hwy 2
 Libby, MT 59923
 Phone: (406) 283-7740
 Fax: (406) 283-7710

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	171.3875	171.3875	TX 123.0	No location given
Air Guard	168.6250	168.6250	TX 110.9	N48 24.0/W115 34.60 (Libby)
Local Contact North "Kootenai Dispatch"	171.3875	171.3875	TX 123.0	N48 24.0/W115 34.60
Local Contact South "Kootenai Dispatch"	171.2625	171.2625	TX 123.0	N48 24.0/W115 34.60
<i>Note: Kootenai Dispatch monitors National FF (168.6500 RX/TX, T:110.9) as a secondary flight following frequency.</i>				

Lewistown Interagency Dispatch Center

920 NE Main St.
 Lewistown, MT 59457
 Phone: (406) 538-1072
 Fax: (406) 538-1062

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	N47 13.0/W109 13.0 (Judith Peak)
Local Contact "Lewistown Fire Dispatch"	172.7250	163.1250	TX 100.0	N47 13.0/W109 13.0 (Judith Peak)

Miles City Interagency Dispatch Center

111 Garryowen Road
Miles City, MT 59301
Phone: (406) 233-2900
Fax: (406) 233-2945

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	RX/TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact "Miles City Dispatch"	165.6000	169.6250	TX 118.8	N46 23.83/W105 51.81 "MCC Direct"

Missoula Interagency Dispatch Center

1803 Strand Avenue
Missoula, MT 59801
Phone: (406) 829-7070
Aircraft Desk: (406) 829-7060
Fax: (406) 829-7061

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following "Missoula Aircraft"	168.6500	168.6500	TX 110.9	N46 51.183/W113 55.750 (University Mountain)
Air Guard "Missoula Aircraft"	168.6250	168.6250	TX 110.9	N46 51.183/W113 55.750 (University Mountain)

Plains Interagency Dispatch Center

Plains, MT

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Lolo West Direct "Plains Dispatch" <i>(Primary Flight Follow)</i>	164.9125	164.9125	TX 123.0	N47 22.4/W114 51.7 (Pat's Knob Lookout)
National Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given

Note: PDC monitors National Flight Following and Air Guard but has limited response capability.

Ronan Dispatch Center

Ponan, MT

Description	Mobile RX	Mobile TX	Tone	Lat/Long
CS&KT Flight Follow "Ronan Dispatch"	166.9250	166.9250	NA	N47 34.03/W114 06.06 (Ronan Airport (7S0))

Note: Ronan Dispatch does not monitor Air Guard

YELLOWSTONE NATIONAL PARK

Yellowstone National Park Emergency Operations Center

Phone: NA

Fax: NA

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N44 47.88/W110 26.07 (Mt Washburn)
Air Guard	168.6250	168.6250	TX 110.9	N44 47.88/W110 26.07 (Mt Washburn)
Local Flight Following "700FOX"	172.5000	172.5000	RX/TX 103.5	N44 47.88/W110 26.07 (Mt Washburn)
North Repeater "700FOX"	166.3250	166.9250	RX/TX 167.9	N44 47.88/W110 26.07 (Mt Washburn)
Lamar Repeater "700FOX"	166.3750	166.9750	RX/TX 192.8	N44 54.25/W110 10.74 (Druid Peak)
South Repeater "700FOX"	165.5875	164.8000	RX/TX 110.9	N44 15.89/W110 32.13 (Mt Sheridan)
West Repeater "700FOX"	166.8750	169.4000	RX/TX 136.5	N44 39.97/W110 51.75 (Purple Mountain)

*Note: National Flight Following 168.6500 TX Tone 110.9 is monitored, but coverage is spotty.
Primary Flight Following is on Fire Cache Ops with backup on other Park Frequencies listed above.*

NORTH DAKOTA

North Dakota Interagency Dispatch Center

3425 Miriam Ave.

Bismarck, ND 58501

Phone: (701) 333-0260

Fax: (701) 333-0269

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	NA	NA	NA	NA
Local Contact	164.9375	164.93750	NA	No Location given

North Dakota has no National Flight Following radio monitoring capabilities.

Note: North Dakota Interagency Dispatch now has "radio over internet" with the Dakota Prairie Grasslands frequencies. Flight Following and Air Guard frequency capability will eventually be available but no timetable for that availability has been determined.

NORTHERN IDAHO

Coeur d'Alene Interagency Dispatch Center

11569 N Airport Drive
Hayden, ID 83835
Phone: (208) 772-3283
Fax: (208) 762-6909/6927

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following**	168.6500	168.6500	TX 110.9	N47 46.56/W116 48.54 (Hayden)
Air Guard	168.6250	168.6250	TX 110.9	N47 37.34/W116 59.31 (Mica Peak)
Repeater (South)	159.3000	151.3250	RX 123.0 TX 100.0	N46 35.47/W116 23.48 (Teaken Butte)
Repeater (Southeast)	168.7250	168.1250	RX 123.0 TX 110.9	N47 5.06/W115 16.50 (Simmons Peak)
Repeater (North)	168.7750	168.1750	RX 123.0 TX 131.8	N48 57.03/W116 46.30 (Saddle Mountain)

*Note: **Coeur d'Alene Dispatch has limited National Flight Following coverage in the extreme south, southeast and north areas of the zone due to the transmit antenna location at the dispatch center. Use Teaken, Simmons, or Saddle repeaters if unable to contact dispatch on National Flight Following.**

Grangeville Interagency Dispatch Center

104 Airport Road
Grangeville, ID 83530
Phone: (208) 983-6800
Fax: (208) 983-4065

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N45 51.70/W116 7.30 (Highcamp)
Air Guard	168.6250	168.6250	TX 110.9	N45 51.70/W116 7.30 (Highcamp)
Repeater (South/West)	170.5625	164.1375	TX 114.8	N45 51.70/W116 7.30 (Highcamp)
Repeater (East)	171.5750	166.2625	TX 100.0	N46 33.8/W114 26.4 (Beaver Ridge)
Repeater (North/Northeast)	170.5000	165.0125	TX 136.5	N46 41.7/W115 16.7 (Junction)
Repeater (South)	170.5625	164.1375	TX 146.2	N45 22.1/W116 29.6 (Heaven's Gate)
Repeater (Central/East)	169.9500	166.2000	TX 156.7	N46 09.9/W114 56.3 (Shissler)

Note: GVC has limited Flight Following coverage in the extreme East and North of the zone. All Highcamp locations have similar coverage and are located on the high point above Grangeville to the south at about 6100 feet and linked via UHF links to the dispatch center at the airport. If unable to contact dispatch on National Flight Following please try on one of the repeaters listed.

This page intentionally left blank.

PACIFIC NORTHWEST



Northwest Interagency Coordination Center
150 SW Harrison Street, Suite 400
Portland, Oregon, 97201-5392
Phone: (503) 808-2720
Fax: (503) 808-2750

OREGON

Blue Mountain Interagency Dispatch Center

59973 Downs Rd.
LaGrande, OR 97850
Phone: (541) 963-7171
Fax: (541) 663-0533

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	N45 25.5/W117 18.0 (Enterprise)
Local Contact	170.5250	164.8000	TX 167.9	N45 26.16/W118 5.27 (Mount Emily)
Local Contact	164.1500	168.1500	TX 136.5	N44 50.192/W118 19.247 (Mount Ireland)
Local Contact	166.0000	164.0250	TX 131.8	N45 15.63/W117 10.575 (Mount Howard)

Burns Interagency Communication Center

28910 Hwy 20 West
Hines, OR 97738
Phone: (541) 573-4552
Fax: (541) 573-4410

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	172.7500	172.7500	RX/TX 77.0	N43 26.80/W119 00.03 (Hines)
Air Guard	168.6250	168.6250	TX 110.9	N43 26.80/W119 00.03 (Hines)
Local Contact King	172.7500	163.1750	RX 77.0 TX 82.5	N43 48.60/W118 52.10 (King Mountain)
Local Contact Steens	172.7500	163.1750	RX 77.0 TX 94.8	N42 38.22/W118 34.65 (Steens Mountain)

Central Oregon Interagency Dispatch Center

4550 Airport Way
Prineville, OR 97754
Phone: (541) 416-6800
Fax: (541) 416-6847

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N44 4.6/W121 19.8 (Awbrey)
Air Guard	168.6250	168.6250	TX 110.9	N44 26.221/W120 57.285 (Grizzly)
Local Contact	173.8375	166.2250	TX 173.8	N44 26.221/W120 57.285 (Grizzly)

Coastal Valley Interagency Dispatch Center

3200 SW Jefferson Way

Corvallis, OR 97331

Phone: (541) 750-7024

Fax: (541) 750-7027

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N44 00.32/W122 15.27 (Indian Ridge)
Air Guard	168.6250	168.6250	TX 110.9	N44 30.58/W122 34.10 (Marys Peak)

Eugene Interagency Communication Center

3106 Pierce Parkway Suite D

Springfield, OR 97477

Phone: (541) 225-6400

Fax: (541) 225-6221

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	164.9375	164.1750	RX 103.5 TX 123.0	N44 12.5/W122 6.10 (Frissell)
Local Contact	164.8250	163.0750	RX 103.5 TX 192.8	N43 50.45/W122 19.12 (Huckleberry)

John Day Interagency Dispatch Center

431 Patterson Bridge Rd.

John day, OR 97845

Phone: (541) 575-1321

Fax: (541) 575-3027

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N44 17.40/W119 2.30
Air Guard	168.6250	168.6250	TX 110.9	N44 17.40/W119 2.30
Local Contact Fire Net	167.5000	167.5000	TX 136.5	N44 17.40/W119 2.30 (Fall Mountain)
Local Contact Fire Net	167.5000	167.5000	TX 123.0	N44 35.0/W118 37.30 (Dixie)

Lakeview Interagency Fire Center

1000 South Ninth Street

Lakeview, OR 97630

Phone: (541) 947-6315

Fax: (541) 947-6317

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N42 29.6/W120 30.3 (Round Pass)
Air Guard	168.6250	168.6250	TX 110.9	N42 15.10/W120 38.17 (Grizzly Peak)
Local Contact	167.1750	167.1750	NA	N42 15.10/W120 38.17 (Grizzly Peak)

Medford Interagency Communications Center

3040 Biddle Rd.

Medford, OR 97504

Phone: (541) 618-2510

Fax: (541) 618-2515

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N42 35.979/W123 21.814 (Sexton)
Air Guard	168.6250	168.6250	TX 110.9	N43 9.36/W122 52.843 (Red Butte) N42 21.639/W122 52.239 (Medford)
Local Contact	169.1750	164.1500	RX 103.5 TX 131.8	N42 37.159/W122 20.883 (Rustler Peak) N42 21.639/W122 52.239 (Medford)

Vale Dispatch Center

100 Oregon St.

Vale, OR 97918

Phone: (541) 473-6295

Fax: (541) 473-3678

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N43 58.60/W117 13.40 (Rhinehart Butte)
Air Guard	168.6250	168.6250	TX 110.9	N43 58.60/W117 13.40 (Rhinehart Butte)
Local Flight Following	171.7750	163.0750	TX 103.5	N44 10.10/W117 39.70 (Cottonwood Mountain)
Local Flight Following	171.7750	163.0750	TX 100.0	N42 44.30/W116 55.0 (South Mountain)

WASHINGTON

Central Washington Communication Center

3796 Airport Way, East Wenatchee WA 98802

Phone: (509) 884-3473, Fax: (509) 884-3549

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	172.2500	166.8000	RX 146.2 TX 100.0	N47 16.54/W120 25 16 (Mission Ridge)

Columbia Cascade Interagency Dispatch Center

10600 NE 51st Circle, Vancouver WA. 98682

Phone: (360) 891-5140, Fax: (360) 891-5145

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following (WA-GPF/OR-MHF East)	168.6500	168.6500	TX 110.9	N45.6438/W122.7222 (Mt Defiance)
Flight Following (OR-MHF West)	168.6500	168.6500	TX 110.9	N45.1061/W122.1189 (Whalehead)
Air Guard	168.6250	168.6250	TX 110.9	N45.6438/W122.7222 (Mt Defiance)
WA-GPF West Side	172.2250	168.7750	RX 123.0 TX 167.9	N46.0314/W122.1917 (Mitchell Repeater)
WA-GPF East Side	172.3250	168.4750	RX 123.0 TX 192.8	N45.6438/W122.7222 (Mt Defiance Repeater)
OR-MHF West Side	170.5250	168.6750	RX 162.2	N45.1061/W122.1189 (Whalehead Repeater)
OR-MHF East Side	169.9250	168.1750	TX114.8	N45.3169/W120.9736 (Flag Point Repeater)

Northeast Washington Interagency Dispatch Center

225 South Silke Rd, Colville WA. 99114

Phone: (509) 685-6900, Fax: (509) 684-2080

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	171.4750	164.6250	RX 146.2 TX 103.5	14.5 miles NE from Chewelah

Puget Sound Interagency Communications Center


2930 Wetmore Suite 1A, Everett WA 98201

Phone: (425) 783-6150, Fax: (425) 783-0239

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N47 27 31/W121 48 21 (Rattlesnake Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N47 27 31/W121 48 21 (Rattlesnake Mountain)

This page intentionally left blank.

ROCKY MOUNTAIN



Rocky Mountain Area Coordination Center
2850 Youngfield Street
Lakewood, CO 80215
Phone: (303) 445-4300
FAX: (303) 445-4319
E-mail: rmacoordctr@gmail.com

COLORADO

Craig Interagency Dispatch Center

455 Emerson Street

Craig CO 81625

Phone: (970) 826-5037

Fax: (970) 826-5051

E-mail: craiginteragency@gmail.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N40 26 58/W108 01 43 (Juniper Mountain) N40 27 23.0/W106 44 23.0 (Mount Werner)
Air Guard	168.6250	168.6250	TX 110.9	N40 27 23.0/W106 44 23.0 (Mount Werner)
Local Contact	164.5250	172.7250	TX 131.8	N40 26 58/W108 01 43 (Juniper Mountain)

Durango Interagency Dispatch Center

15 Burnett Court

Durango CO 81301

Phone: (970) 385-1324

Fax: (970) 385-1386

E-mail: durangodispatch@yahoo.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N37 33/W108 44 (Yellow Jacket) N37 16/W107 54 (Smelter) N37 30/W106 48 (Wolf Creek)
Air Guard	168.6250	168.6250	TX 110.9	N37 33/W108 44 (Yellow Jacket) N37 16/W107 54 (Smelter) N37 30/W106 48 (Wolf Creek)
Local Contact	169.9250	169.9250	TX 110.9	N37 15.72/W107 54.35 (Smelter Base)

Fort Collins Interagency Dispatch Center

2150 Centre Ave. Bldg E

Fort Collins, CO 80526

Phone: (970) 295-6800

Fax: (970) 295-6801

E-mail: fortcollinsdispatch@yahoo.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N39 40.82/W105 29.66 (Squaw Mountain) N40 36.68/W105 19.40 (Buckhorn Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N40 36.68/W105 19.40 (Buckhorn Mountain) N39 40.82/W105 29.66 (Squaw Mountain)
Local Contact	169.1750	169.1750	NA	N40 36.68/W105 19.40 (Buckhorn Mountain)

Grand Junction Interagency Dispatch Center

2774 Landing View Lane

Grand Junction, CO, 81506

Phone: (970) 257-4800

Fax: (970) 257-4855

E-mail: gjcdispach@gmail.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N39 05.2/W108 13.3 (Lands End) N39 25.6/W107 22.5 (Sunlight)
Air Guard	168.6250	168.6250	TX 110.9	N39 05.2/W108 13.3 (Lands End) N39 25.6/W107 22.5 (Sunlight)
Tanker Base Ramp	123.9750	123.9750	NA	N39 07.3/W108 31.6 Grand Junction Tanker Base
Local Contact	172.1125	172.1125	NA	N39 05.2/W108 13.3 (Lands End)
Local Contact	169.7750	169.7750	TX 77.0	N39 32.6/W107 17.8 (Lookout)

Montrose Interagency Dispatch Center

2465 S. Townsend Ave

Montrose, CO 81401

Phone: (970) 249-1010

Fax: (970) 240-5369

E-mail: montrosedispatch@yahoo.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N38 20.0/W107 38.00 (Storm King)
Air Guard	168.6250	168.6250	TX 110.9	N38 20.0/W107 38.00 (Storm King)
Local Contact	170.0250	170.0250	TX 173.8	N38 20.0/W107 38.00 (Storm King)

Pueblo Interagency Dispatch Center

2840 Kachina Drive

Pueblo, CO 81008

Phone: (719) 553-1600

Fax: (719) 553-1616

E-mail: pueblodispatch@yahoo.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N37 43.52/W106 35.18 (Agua Ramone) N38 50.80/W105 2.63 (Pikes Peak)
Air Guard	168.6250	168.6250	TX 110.9	N38 50.8/W105 2.63 (Pikes Peak)
Local Contact (Pike Direct)	168.7250	168.7250	TX 123.0	N38 50.8/W105 2.63 (Pikes Peak)
Local Contact (San Isabel Direct)	169.9000	169.9000	TX 131.8	N38 27.13/W106 01.06 (Methodist Mountain)
RGF Direct	164.1500	164.1500	TX 123.0	N37 43.52/W106 35.18 (Agua Ramone)
Pueblo Tanker Base Ramp	124.4250	124.4250	NA	N38 17.34/W104 29.79 (Pueblo Memorial Airport)

SOUTH DAKOTA

Northern Great Plains Interagency Dispatch Center

8123 S. Hwy 16
Rapid City, SD 57702
Phone: (605) 399-3160
Fax: (605) 343-5075

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N43 52.18/W103 44.60 (Bear Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N43 52.18/W103 44.60 (Bear Mountain)
Local Contact (Forest Net)	169.1750	169.1750	TX 103.5	N43 52.18/W103 44.60 (Bear Mountain)

WYOMING

Cody Interagency Dispatch Center

2501 Wright Brothers Rd., Cody WY 82414
Phone: (307) 578-5740
24 Hour: (800) 295-9954
Fax: (307) 578-5759
E-mail: codydispatch@gmail.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N43 26.25/W107 59.95 (Cooper Mountain) N44 29.80/W109 09.00 (Cedar Mountain) N44 35.70/W107 22.90 (Dome Peak)
Air Guard	168.6250	168.6250	TX 110.9	N43 26.25/W107 59.95 (Cooper Mountain) N44 11.70/W109 25.10 (Carter Mountain) N44 35.70/W107 22.90 (Dome Peak)
Local Contact	168.5250	172.4375	TX 131.8	N43 26.25/W107 59.95 (Cooper Mountain)


Casper Interagency Dispatch Center
 2987 Prospector Drive, Casper WY 82604
 Phone: (307) 261-7691
 24 Hour: (800) 295-9952
 Fax: (307) 261-7646
 E-mail: casper_dispatch@yahoo.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N42 44.58/W106 13.42 (Casper Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N42 44.58/W106 13.42 (Casper Mountain)
Local Contact (Forest Net)	168.3000	168.3000	NA	N42 44.58/W106 13.42 (Casper Mountain)

Rawlins Interagency Dispatch Center
 1300 North 3rd Street
 P.O. Box 2407
 Rawlins WY 82301
 Phone: (800) 295-9953
 Fax: (307) 328-4229
 E-mail: rawlinsdispatch@yahoo.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N41 37.96/W106 31.63 (Elk Mountain) N41 25.667/W109 7.233 (Aspen Mountain) N42 51.983/W109 51.48 (Pinedale)
Air Guard	168.6250	168.6250	TX 110.9	N41 37.96/W106 31.63 (Elk Mountain) N41 25.667/W109 7.233 (Aspen Mountain) N42 51.983/W109 51.48 (Pinedale)
Local Contact	168.2750	168.2750	NA	N41 40.73/W107 14.23 (Sheep Mountain)
Local Contact	168.5750	168.5750	NA	N41 25.667/W109 7.233 (Aspen Mountain) N42 51.983/W109 51.48 (Pinedale)

SOUTHERN



Southern Area Coordination Center
1200 Ashwood Parkway, Ste 230
Atlanta, GA 30338
Phone: (678) 320-3000
Fax: (678) 320-3036

ARKANSAS/OKLAHOMA

Arkansas/ Oklahoma Interagency Coordination Center

"Hot Springs Dispatch"

110 Indiana St.

Hot Springs, AR 71901

Phone: (501) 321-5232

24/7: (501) 574-8758

Fax: (501) 627-0633

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N35 9.883/W93 40.80 (Magazine)
Air Guard	168.6250	168.6250	TX 110.9	N35 29.569/W93 3.299 (Hot Springs)
Local Flight Following	168.7500	168.7500	TX 110.9	N35 9.883/W93 40.80 (Magazine)
Local Contact	169.6750	170.5000	TX 103.5	N34 43.80/W93 13.566 (Pinnacle Mountain)

FLORIDA

Florida Interagency Coordination Center

"Tallahassee Dispatch"

3250 Capital Circle SW

Tallahassee, FL 32010

Phone: (850) 523-8600

Fax: (850) 523-8621

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	170.5000	164.1250	TX 167.9	N30 21.5/W84 38.9 (FSU Tower)

GEORGIA

Georgia Interagency Coordination Center

"Gainesville Dispatch"

1755 Cleveland Hwy.

Gainesville, GA 30501

Phone: (770) 297-3036

Fax: (770) 297-3034

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	168.7750	168.7750	TX 136.5	N34 20.13/W83 48.51 (Gainesville)

KENTUCKY

Kentucky Interagency Coordination Center

"Daniel Boone Dispatch"

1700 Bypass Road

Winchester, KY 40391

Phone: (859) 745-3171

Fax: (859) 744-7086

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact North	164.9125	164.9125	TX 103.5	No location given
Local Contact South	164.8000	164.8000	TX 103.5	No location given
Local Contact Redbird	164.9375	164.9375	TX 103.5	N37 59.63/W84 12.85 (Winchester)

LOUISIANA

Louisiana Interagency Coordination Center

"Pineville Dispatch"

2500 Shreveport Highway

Pineville, LA 71360

Phone: (318) 473-7152

Fax: (318) 473-7172

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	169.9250	169.9250	TX 110.9	N31 21.33/W92 26.057 (Pineville)

NORTH CAROLINA

North Carolina Interagency Coordination Center

"Asheville Dispatch"

160A - Zillico St.

Asheville, NC 28801

Phone: (828) 257-4264

Fax: (828) 257-4804

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N35 36.44/W82 34.12 (Asheville)
Air Guard	168.6250	168.6250	TX 110.9	N35 36.44/W82 34.12 (Asheville)
Local Contact	168.7250	172.2250	RX 103.5 TX 136.5	N35 44.13/W82 17.13 (Clingman)

SOUTH CAROLINA

South Carolina Interagency Coordination Center

"Columbia Dispatch"
4931 Broad River Rd.
Columbia, SC 29212
Phone: (803) 561-4086
Fax: (803) 561-4085

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	168.6750	168.1250	TX 146.2	N34 4.38/W81 7.43 (Columbia)

TENNESSEE

Tennessee Interagency Coordination Center

"Cherokee Dispatch"
2800 North Ocoee St.
Cleveland, TN 37312
Phone: (423) 476-9775
Fax: (423) 476-9792

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact North	169.8750	169.8750	TX 103.5	No location given
Local Contact South	169.9250	169.9250	TX 103.5	N35 10.82/W84 51.69 (Cleveland)
Chattanooga Air Tanker	128.4250	128.4250	NA	N35 2.49/W85 12.40 (CHA Air Tanker Base)

TEXAS

Texas Interagency Coordination Center

1097 Texas Forest Service Loop
Lufkin, TX 75904
Phone: (936) 875-4786
Fax: (936) 875-4812

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Lufkin Dispatch	171.4750	171.4750	TX 100.0	N31 18.47/W94 49.34
TFS Henderson Dispatch	159.4200	159.4200	TX 123.0	N32 9.99/W94 48.63
TFS LaGrange Dispatch	159.3300	151.3100	RX 186.2 TX 179.9	N29 54.46/W96 51.60
TFS Linden Dispatch	159.3750	159.3750	TX 110.9	N33 0.31/W94 21.496
TFS Livingston Dispatch	159.3750	159.3750	RX/TX 94.8	N30 42.52/W94 53.85

VIRGINIA

Virginia Interagency Coordination Center

"Roanoke Dispatch"

5162 Valley Pointe Parkway

Roanoke, VA 24019


Phone: (540) 265-5221

Fax: (540) 265-5225

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9*	No location given
Local Contact	171.5250	172.3250	TX 167.9	N37 31.02/W79 30.55 (Apple Orchard)
* Not programmed in Base Radio				

This page intentionally left blank.

SOUTHWEST



Southwest Coordination Center
333 Broadway Blvd. SW
Albuquerque, NM 87102
Phone: (505) 842-3473
Fax: (505) 842-3801

ARIZONA

Arizona Dispatch Center

2901 W Pinnacle Peak Rd.

Phoenix, AZ 85027

Phone: (623) 582-0911

Fax: (623) 445-0288

E-mail: aidc@azsf.gov

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	RX/TX 110.9	West Central AZ-Hayden & Smith pk
State Flight Following	154.9350	154.9350	TX 110.9	Statewide
Air Guard	168.6250	168.6250	TX 110.9	Locally monitored by ADC
State Channel 1	151.4000	159.4050	RX/TX 162.2	Williams-Phoenix-Tucson
State Channel 2	151.4150	159.4350	RX/TX 123.0	Tucson-Showlow-Precsott-Phoenix
State Channel 3	151.4150	159.4350	RX/TX 162.2	Kingman-Globe-Douglas
State Channel 4	151.4000	159.4050	RX/TX 123.0	Flagstaff-Stafford-Kingman-Yuma

Flagstaff Interagency Dispatch Center

1824 S. Thompson ST.

Flagstaff, AZ 86001

Phone: (928) 526-0600

Fax: (928) 779-5267

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	171.5500	173.0250	TX 146.2	N35 14.5/W111 35.6 (Mount Elden)

Phoenix Interagency Fire Center

6335 S. Downwind Circle, Suite 101

Mesa AZ 85212

Phone(480) 457-1551

Fax: (480) 279-6595

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact Tonto National Forest	164.8250	164.1250	TX 123.0	N33 54.10/W111 24.60 (Mount Ord)
Local Contact San Carlos	172.4250	166.23750	RX 151.4 TX 162.2	N33 16.6/W110 19.4 (Pinal)
Local Contact Pima	169.7125	166.23750	RX 103.5 TX 114.8	N33 00.30/W111 40.20 (Sacaton Mountain)
PHD	172.5250	163.0375	TX 103.5	N33 34.68/W112 34.31 (White Tanks)

Prescott Interagency Dispatch Center

2400 Melville Drive, Prescott AZ 86301

Phone: (928) 777-5700

Fax: (928) 777-5609

E-mail: Prescott.dispatch@gmail.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Prescott National Forest	173.9250	165.7500	TX 110.9	No location given
DOI North	170.5125	164.2500	TX 127.3	No location given
DOI South	173.8250	163.5750	TX 131.8	No location given

Show Low Interagency Dispatch Center

1400 N. Airport Drive Suite 1, Show Low AZ 85901

Phone: (928) 532-2700

Fax: (928)-537-5328

E-mail: showlowdispatch@gmail.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact East	169.8750	169.8750	NA	N34 6.9/W109 34.5 (Greens Peak)
Local Contact West	169.9500	169.9500	NA	N34 6.9/W109 34.5 (Greens Peak)

Tucson Interagency Dispatch Center

2646 E. Commerce Center Place, Tucson AZ 85706

Phone: (520) 202-2710

Fax: (520) 807-7065

E-mail: tucsondispatch@gmail.com

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N32 26.4/W110 47.2
Air Guard	168.6250	168.6250	TX 110.9	N32 26.4/W110 47.2
Local Contact	168.1500	172.2750	TX 114.8	N31 41.18/W110 53.0 (Hopkins)

Williams Interagency Dispatch Center800 South 6th Street, Williams AZ 86046

Phone: (928) 635-2601

Fax: (928) 635-2728

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact North	168.7500	168.7500	TX 103.5	No location given
Local Contact South	170.5500	170.5500	TX 103.5	N35 12.08/W112 12.3 (Bill Williams Mountain)

NEW MEXICO

Alamogordo Interagency Dispatch Center

3500 Airport Road
Alamogordo, NM 88310
Phone: (575) 437-2286
Fax: (575) 437-7908

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N33 24.25/W105 46.90 (Buck Mountain)
Air Guard	168.6250	168.6250	TX 110.9	N33 00.1/W105 43.00 (Wofford Mountain)
Local Contact North	170.5000	170.5000	RX/TX 103.5	N33 24.25/W105 46.90 (Buck Mountain)
Local Contact South	173.7750	173.7750	RX/TX 103.5	N32 48.70/W105 48.00 (Cathey Peak)

Albuquerque Interagency Dispatch Center

2113 Osuna Rd. NE Suite A
Albuquerque, NM 87113
Phone: (505) 346-2660
Fax: (505) 346-3911

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact	170.5250	170.5250	TX 110.9	N35 15.08/W107 35.81 (La Mosca)

Santa Fe Interagency Dispatch Center

11 Forest Lane
Santa Fe, NM 87508
Phone: (505) 438-5600
Fax: (505) 424-8457

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	No location given
Air Guard	168.6250	168.6250	TX 110.9	No location given
Local Contact West	172.3000	165.0125	TX 103.5	No location given
Local Contact East	171.5500	164.8750	TX 103.5	N35 47.20/W105 46.90 (Tesque Peak)

Silver City Interagency Dispatch Center

3005 E. Camino Del Bosque

Silver City, NM 88061

Phone: (575) 538-5371

Fax: (575) 388-8359

E-mail: nmsdc@fs.fed.us

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N33 46.0/W108 52.5 (Frisco Divide)
Air Guard	168.6250	168.6250	TX 110.9	N32 54.90/W108 53.70 (Signal Peak)
Local Contact South	169.1750	169.1750	NA	N32 54.90/W108 53.70 (Signal Peak)
Local Contact North	169.9750	169.9750	NA	N33 46.0/W108 52.5 (Frisco Divide)

Taos Interagency Dispatch Center

208 Cruz Alta Rd.

Taos, NM 87571

Phone: (575) 758-6208

Fax: (575) 758-6207

Description	Mobile RX	Mobile TX	Tone	Lat/Long
Flight Following	168.6500	168.6500	TX 110.9	N36 23.23/W105 34.8 (Taos)
Air Guard	168.6250	168.6250	TX 110.9	N36 23.23/W105 34.8 (Taos)
Local Contact	169.1750	169.1750	NA	N36 12.0/W105 42.0 (Picurus)

This page intentionally left blank.

APPENDICES

Appendix A: TDFM-136/A Quick Reference

Appendix B: TDFM-136B Quick Reference

Appendix C: NPX-136D Operations Summary

Appendix D: National Flight Following

This page intentionally left blank.

APPENDIX A

TDFM-136/A COMMAND QUICK REFERENCE

Radio Firmware 3.x.x

TiL 3342 E





For Radio Firmware: 3.x.x



1. LED channel squelch indicators – Lights when signal received (Top: Main, Bottom: Guard).
2. Channel parameter display – (2 line by 24 character LED display) (Top: Main, Bottom: Guard).
3. MAIN (Rotary+Switch) – Power ON/OFF and Main channel volume control.
4. GUARD (Rotary) – Guard channel volume control.
5. Squelch Defeat (Push button) – Press to open squelch (in analog modes of operation)
6. Keyloader/Data Port – Not available on some models. Use with KVL 3000+ keyloader. Data for some TDFM-136A's (SN FDA 1200 & up) only.
7. **MN/GD** (Toggle Switch) – Selects active channel (main or guard), **for transmit and memory edit.**
8. **G1/G2** (Toggle Switch) – Selects guard memory (GD1 or GD2), for transmit and edit.
9. **HI/LO** (Toggle Switch) – Selects transmit power, high (10W) or low (1W).
10. **KEYPAD** (12 Keys) – Control radio functions, 3 command levels as follows:

Basic functions on L1 Command Level 1: press the desired "Cmnd" key				
Cmnd	Function	Edit Keys	OK	Exit
	SELECT CHANNEL MEMORY	TO ENTER THREE DIGIT CHANNEL NUMBER INTO MEMORY (001 to 230)		
	DISPLAY BRIGHTER			
	EDIT OPERATING MODE	STEP UP/DOWN THROUGH OPERATING MODES (" n " or " D ")		
*	SCROLL CHANNEL DOWN	SCROLL DOWN THROUGH PROGRAMMED/ACTIVE MEMORY CHANNELS		
	SCAN ON/OFF	OR STOP SCAN		
*	SCROLL CHANNEL UP	SCROLL UP THROUGH PROGRAMMED/ACTIVE MEMORY CHANNELS		
*	EDIT FREQUENCY	TO SELECT Rx FREQUENCY THEN REPEAT FOR Tx FREQUENCY		
	DISPLAY DIMMER			
*	EDIT TONE or CODE	STEP UP/DOWN THROUGH SQUELCH MODES. Tx FOLLOWS Rx.		
	Tone: P25 Code: x - Off m - Monitor (i.e. x) t - On n - NAC only c - Code g - TGID + NAC	STEP UP/ DOWN THROUGH: TONES , CODES, TGID & NAC (\$ = HEX) TO DECIMAL EDIT FOR NOISE SQL VALUE (00 TO 15)		
	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL		
*	TOGGLE HOME/CURRENT	TOGGLE BETWEEN 'HOME' CHANNEL AND CURRENTLY DISPLAYED CHANNEL.		
	TOGGLE TALK AROUND	FOR DUPLEX CHANNELS: RADIO USES RX INFORMATION FOR TX. "UP" ARROW		

Press  to get to Command Level 2, then press the desired "Cmnd" key				
Cmnd	Function	Edit Keys	OK	Exit
* 	CREATE or EDIT CHANNEL	 TO  SELECT CHANNEL MEMORY TO EDIT THEN EDIT: SCAN LIST (L2-5), TEXT DESCRIPTION (L2-6) OPERATING MODE (L1-3), FREQUENCY (L1-7), & SQUELCH (L1-9)		
	COPY GUARD TO MAIN	COPY CHANNEL INFORMATION FROM GUARD TO MAIN (default disabled)		
* 	LOCK KEYPAD	PRESS & HOLD  TO UNLOCK KEYPAD		
	n/u			
	EDIT SCAN LISTS	   STEP UP/DOWN THROUGH AVAILABLE SCAN LISTS  TOGGLE ENABLE/DISABLE FOR SCAN (BAR OVER DIGIT = DISABLED)		
* 	EDIT CHANNEL TEXT	 STEP THROUGH THE FOUR CHARACTER GROUPS (AZ, az, 09, and BLANK/)   SCROLL UP & DOWN THROUGH CHARACTERS IN SELECTED GROUP   MOVE CURSOR LEFT & RIGHT		
	CREATE SHADOW	 TO  SELECT CHANNEL MEMORY TO EDIT THEN EDIT: TEXT (L2-6), MODE (L1-4), SQUELCH (L1-9)		
	COPY MAIN TO GUARD	COPY CHANNEL INFORMATION FROM MAIN TO GUARD (default disabled)		
	TOGGLE ENCRYPTION	TOGGLE ENCRYPTION ON/OFF (ONLY FOR MEMORIES WITH KEY ASSIGNED)		
	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL		
	SET HOME CHANNEL	SET 'HOME' CHANNEL INTO MEMORY (FOR MAIN RADIO ONLY).		
	GO TO PREVIOUS LEVEL	GO TO THE PREVIOUS COMMAND LEVEL		

Press  +  to get to Command Level 3, then the desired "Cmnd" key				
Cmnd	Function	Edit Keys	OK	Exit
	SET BOOT CHANNEL	   STEP UP/DOWN THROUGH BOOT MEMORY OPTIONS		
	ASSIGN KEY BY KEYTAG	  PICK MEMORY,   PICK KEY,   PICK DECRYPT OPTION		
* 	SET P25 MODE	   TOGGLE P25 HEX/DECIMAL EDIT MODE (FOR TGID & NAC CODES)		
	DISPLAY FIRMWARE REV.	   STEP THROUGH MAIN & BOOT FIRMWARE VERSIONS		
	SET SCAN PARAMETERS	   SELECT REVERT MODE THEN  TO  SET TIMERS (REPLY, MONITOR, DELAY)		
	SET PTT TIMER	   STEP UP/DOWN THROUGH TIMER VALUES (30, 60, 90 SEC)		
* 	SET SIDETONE AUDIO	 TO  SET SIDETONE LEVEL (00 TO 85) (TDFM-136=52, TDFM-136A=68)		
	PC COMMUNICATION	MUST BE CONNECTED TO A PC OPERATING TDP-136 SOFTWARE		
* 	SHOW TONES/CODES	   TOGGLE Rx/Tx SQUELCH PARAMETER DISPLAY (CHECK TONES)		
	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL (L4 PASSWORD PROTECTED)		
	n/u			
	GO TO PREVIOUS LEVEL	GO TO THE PREVIOUS COMMAND LEVEL		

NOTES:

- The channel being edited is determined by the position of the front panel switches MN/GD and G1/G2.
- Current command level is shown at 4th character on bottom row (between GD2 and text).
- Levels 2 & 3 time out. The radio will return to Level 1 if a "Cmnd" key is not entered within 5 seconds.**
- Download this Quick Reference Guide @ www.nifc.gov/NIICD/documents.html

This page intentionally left blank.

APPENDIX B


TDFM-136B COMMAND QUICK REFERENCE

Radio Firmware 1.x.x

TiL D8RE394



For Radio Firmware: 1.x.x



1. LED channel squelch indicators – Lights when signal received (Top: Main, Bottom: Guard).
2. Channel parameter display – (2 line by 24 character LED display) (Top: Main, Bottom: Guard).
3. **MAIN** Multi-function rotary encoder (default: Main volume, **press for ON, press & hold for OFF**).
4. **GUARD** Multi-function rotary encoder (default: Guard volume, **press for Squelch defeat**).
5. Data port – for use with KVL 3000+ keyloader or TDP-136 Programming software. Need USB Driver.
6. **MN/GD** (Toggle Switch) – Selects active channel (main or guard), **for transmit and memory edit**.
7. **G1/G2** (Toggle Switch) – Selects guard memory (GD1 or GD2), for transmit and edit.
8. **HI/LO** (Toggle Switch) – Selects transmit power, high (10W) or low (1W).
9. **KEYPAD** (12 Keys) – Control radio functions, 3 command levels as shown below.

Basic functions on L1 Command Level 1: press the desired "Cmnd" key				
Cmnd	Function	Edit Keys	OK	Exit
1 CHAN	SELECT CHANNEL MEMORY	0 PROG TO 9 SQL ENTER THREE DIGIT CHANNEL NUMBER INTO MEMORY (001 to 230)	# ENTER	* ESC
2 (up arrow)	DISPLAY BRIGHTER			
3 MODE	EDIT OPERATING MODE	3 MODE 2 (up arrow) 8 (down arrow) STEP UP/DOWN THROUGH OPERATING MODES ("n" or "D")	# ENTER	* ESC
* 4 (left arrow)	SCROLL CHANNEL DOWN	SCROLL DOWN THROUGH PROGRAMMED/ACTIVE MEMORY CHANNELS		
5 SCAN	SCAN ON/OFF	5 SCAN OR * ESC STOP SCAN		
* 6 (right arrow)	SCROLL CHANNEL UP	SCROLL UP THROUGH PROGRAMMED/ACTIVE MEMORY CHANNELS		
* 7 FREQ	EDIT FREQUENCY	0 PROG TO 9 SQL SELECT Rx FREQUENCY THEN # ENTER REPEAT FOR Tx FREQUENCY	# ENTER	* ESC
8 (down arrow)	DISPLAY DIMMER			
* 9 SQL	EDIT TONE or CODE	9 SQL 2 (up arrow) 8 (down arrow) STEP UP/DOWN THROUGH SQUELCH MODES. Tx FOLLOWS Rx.	# ENTER	* ESC
	Tone: P25 Code: x - Off m - Monitor (i.e. x) t - On n - NAC only c - Code g - TGID + NAC	2 (up arrow) 8 (down arrow) STEP UP/ DOWN THROUGH: TONES , CODES, TGID & NAC (\$ = HEX) 0 PROG TO 9 SQL DECIMAL EDIT FOR NOISE SQL VALUE (00 TO 15)	# ENTER	* ESC
0 PROG	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL		
* # ENTER	TOGGLE HOME/CURRENT	TOGGLE BETWEEN 'HOME' CHANNEL AND CURRENTLY DISPLAYED CHANNEL.		
* * ESC	TOGGLE TALK AROUND	FOR DUPLEX CHANNELS: RADIO USES Rx INFORMATION FOR Tx. "UP" ARROW.		

Press  to get to Command Level 2, then press the "Cmnd" key				
Cmnd	Function	Edit Keys	OK	Exit
* 	CREATE or EDIT CHANNEL	 TO  SELECT CHANNEL MEMORY TO EDIT THEN EDIT: SCAN LIST (L2-5), TEXT DESCRIPTION (L2-6) OPERATING MODE (L1-3), FREQUENCY (L1-7), & SQUELCH (L1-9)		
	COPY GUARD TO MAIN	COPY CHANNEL INFORMATION FROM GUARD TO MAIN (default disabled)		
* 	LOCK KEYPAD	PRESS & HOLD  TO UNLOCK KEYPAD		
	n/u			
	EDIT SCAN LISTS	   STEP UP/DOWN THROUGH AVAILABLE SCAN LISTS  TOGGLE ENABLE/DISABLE FOR SCAN (BAR OVER DIGIT = DISABLED)		
* 	EDIT CHANNEL TEXT	 STEP THROUGH THE FOUR CHARACTER GROUPS (AZ, az, 09, "BLANK")   SCROLL UP & DOWN THROUGH CHARACTERS IN SELECTED GROUP   MOVE CURSOR LEFT & RIGHT		
	CREATE SHADOW	 TO  SELECT CHANNEL MEMORY TO EDIT THEN EDIT: TEXT (L2-6), MODE (L1-4), SQUELCH (L1-9)		
	COPY MAIN TO GUARD	COPY CHANNEL INFORMATION FROM MAIN TO GUARD (default disabled)		
	TOGGLE ENCRYPTION	TOGGLE ENCRYPTION ON/OFF (ONLY FOR MEMORIES WITH KEY ASSIGNED)		
	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL		
	SET HOME CHANNEL	SET THE "HOME" CHANNEL INTO MEMORY (FOR MAIN RADIO ONLY)		
	GO TO PREVIOUS LEVEL	GO TO THE PREVIOUS COMMAND LEVEL		

Press  +  to get to Command Level 3, then the desired "Cmnd" key				
Cmnd	Function	Edit Keys	OK	Exit
	SET BOOT CHANNEL	   STEP UP/DOWN THROUGH BOOT MEMORY OPTIONS		
	ASSIGN KEY BY KEYTAG	  PICK MEMORY,   PICK KEY,   PICK DECRYPT OPTION		
* 	SET P25 MODE	   TOGGLE P25 HEX/DECIMAL EDIT MODE (FOR TGID & NAC CODES)		
	DISPLAY FIRMWARE REV.	   STEP THROUGH RADIO MAIN & BOOT FIRMWARE VERSIONS		
	SET SCAN PARAMETERS	   SELECT REVERT MODE THEN  TO  SET TIMERS (REPLY, MONITOR, DELAY)		
	SET PTT TIMER	   STEP UP/DOWN THROUGH TIMER VALUES (30, 60, 90 SEC)		
* 	SET SIDETONE AUDIO	 TO  SET SIDETONE LEVEL (00 TO 255) (TDFM-136B = 44)		
	PC COMMUNICATION	MUST BE CONNECTED TO A PC OPERATING TDP-136 SOFTWARE		
* 	SHOW TONES/CODES	   TOGGLE Rx/Tx SQUELCH PARAMETER DISPLAY (Check Tones)		
	GO TO NEXT LEVEL	GO TO THE NEXT HIGHER COMMAND LEVEL (L4 PASSWORD PROTECTED)		
	n/u			
	GO TO PREVIOUS LEVEL	GO TO THE PREVIOUS COMMAND LEVEL		

NOTES:

- The channel being edited is determined by the position of the front panel switches MN/GD and G1/G2.
- Current command level is shown at 4th character on bottom row (between GD2 and text).
- Levels 2 & 3 time out. The radio will return to Level 1 if a "Cmnd" key is not entered within 5 seconds.**
- Download this Quick Reference Guide @ www.nifc.gov/NIICD/documents.html

This page intentionally left blank.

APPENDIX C


NPX-136D OPERATIONS SUMMARY



1: Power On/Off

Rotate **MN** knob past detent cw/ccw.

2: Display Layout (Normal Operating Mode)



Toggle the **DISP +/-** Switch to view receive or transmit frequency.

3: Modes of Operation

The SCAN / NORM / GD TX switch on the upper right of the faceplate controls the operating modes of the radio. For normal operation put this switch in the center position. All operation in the following sections assumes the radio is in normal operating mode. To return from any editing menu press **Esc** until normal operating mode is displayed.

4: Display Illumination Level

Press **Menu**, Settings Menu? is displayed.

Press **Enter**, DspIBrt Lt<Off/On>: XXXX is displayed.

Press the **▲ / ▼** arrow buttons to change illumination level 01-20.

Press **Esc**, Save Settings? is displayed, press **Enter**.

5: Scroll Channels Up/Down

Toggle the **CHAN** switch + / - , or press the **► / ◄** buttons

6: Select a Specific Channel

Press the **0-9** buttons, Goto Channel : XXXX then **Enter**.

7: Edit a Frequency

Select the channel to edit.

Press **Menu** until Channel Menu? is displayed.

Press **Enter**, Edit Main? is displayed.

Press **Enter**, RxFreq: MMM.kkkk is displayed.

Press the **0-9** buttons to enter the frequency.

Press **Menu**, TxFreq: MMM.kkkk is displayed.

Press the **0-9** buttons to enter the frequency.

Press **Esc**, Save Changes? is displayed, press **Enter**.

8: Radio TX Mode for Direct / Repeater (all channels)

Press **Menu**, Settings Menu? is displayed.
Press **Enter**, then press **Menu** until Tx Mode:XXXX is displayed.
Press the ▲ / ▼ arrow buttons to select Simplex, Duplex
Direct operation is simplex, repeater operation is duplex.
Press **Esc**, Save Settings? is displayed, press **Enter**.

9: Edit a Tone

Select the channel to edit.
Press **Menu** until Channel Menu? is displayed.
Press **Enter**, Edit Main? is displayed.
Press **Enter**, then press **Menu** until Rx Tn Type:XXXX is displayed.
Press the ▲ / ▼ arrow buttons to select None, Ctcss, Dcs
Press **Menu**, Rx Tone: XXXX is displayed.
Press the ▲ / ▼ arrow buttons to select tone.
Press **Menu**, Tx Tn Type:XXXX is displayed.
Press the ▲ / ▼ arrow buttons to select None, Ctcss, Dcs
Press **Menu**, Tx Tone:XXXX is displayed.
Press the ▲ / ▼ arrow buttons to select tone.
Press **Esc**, Save Changes? is displayed, press **Enter**.

10: Radio Transmit Power selection: Hi or Lo

Press **Menu** until Settings Menu? is displayed.
Press **Enter**.
Press **Menu** until Tx Pwr:XXXX is displayed.
Press the ▲ / ▼ arrow buttons to select H₁, L₀, Per Chan
Press **Esc**, Save Settings? is displayed, press **Enter**.

11: Channel Transmit Power selection: Hi or Lo

Note: Available only when the radio transmit power is set to Per Chan from the settings menu.

Press **Menu** until Channel Menu? is displayed.
Press **Enter** twice, then **Menu** until Tx Power:XXXX is displayed.
Press the ▲ / ▼ arrow buttons to select H₁, L₀.
Press **Esc**, Save Changes? is displayed, press **Enter**.

This page intentionally left blank.

APPENDIX D

Toning Of National Flight Following



Interagency Aviation TECH BULLETIN



No. IA 2010-02

February 26, 2010

Page 1 of 2

Subject: Interagency Guidance on Toning of the National Flight Following Frequency
Distribution: All Users of National Flight Following

During the 2008 National Interagency Radio Meeting, an agreement was reached between the USDA Forest Service and the Department of the Interior (DOI) requiring tone protection on the National Flight Following (NFF) frequency (168.650 MHz, narrowband analog) to avoid radio interference.

The DOI Office of the Chief Information Officer (OCIO) Directive 2009-009 and USDA Forest Service Memorandums dated August 13 and August 14, 2009, authorized and provided guidance on implementation. The project to implement NFF toning is to be completed by May 31, 2010.

The implementation is a three-phase approach managed by the Interagency Radio Alliance (IRA). The following guidance is provided by the Interagency Interoperability Oversight Group (IIOG):

- **Phase I: NFF toning action plan data collection.** Phase I consists of radio technicians and telecommunications managers collecting data on what will be required to tone NFF during the implementation of Phase II and Phase III.
 - Phase I has been completed.
- **Phase II: Tone radio transmitters.** Phase II consists of toning the transmitters of all base station and aircraft radios using this frequency, without exception. All transmitters operating on NFF must be programmed to transmit the Continuous Tone-Controlled Squelch System (CTCSS) tone of 110.9 Hz.
 - Phase II for base stations (ground) has been completed.
 - Phase II for aircraft (air) has begun and must be completed **no later than** March 26, 2010.

Fire and Aviation Management is responsible for ensuring all aircraft have complied with this direction and should verify for proper configuration.

It is important that the Phase II toning of transmitters is done no later than the date specified above. If the transmitters are not toned before the receivers are toned in Phase III, then there will be a loss of communications.

- **Phase III: Tone radio receivers.** Phase III consists of toning the receivers of all base stations and aircraft radios using this frequency, without exception. All receivers operating on NFF must be programmed to accept the CTCSS tone of 110.9 Hz.
 - Phase III for aircraft (air) shall begin **no earlier than** March 29, 2010, and be completed **no later than** May 28, 2010.
 - Phase III for base stations (ground) shall begin **no earlier than** April 19, 2010, and must be completed **no later than** June 25, 2010.

Fire and Aviation Management is responsible for ensuring all aircraft have complied with this direction and should verify for proper configuration.

It is important that the Phase III toning of receivers is done no earlier than the date specified above. Toning the receiver before the transmitters are toned in Phase II will result in the loss of communications.

- **Exception areas due to safety:**

- Due to chronic interference issues affecting aviation safety, the following areas are authorized to immediately implement Phases II and III (ground and air):
 - CA: Los Padres NF, Angeles NF, Cleveland NF, San Bernardino NF
 - AZ: Coronado NF, Tonto NF, Apache-Sitgreaves NF (AZ and NM)
 - NM: Gila NF, Cibola NF, Lincoln NF, Santa Fe NF

Progress of these activities is being monitored on a monthly basis by the IIOG through reporting by the IRA.

Any questions or concerns relating to this project should be directed to the appropriate IRA representative:

USDA: Avionics: Frank Smith, fsmith@fs.fed.us, 208-387-5648
Jimmie Porter, jporter@fs.fed.us, 541-383-5741
DOI: Russ Sveda, russell_sveda@os.doi.gov, 303-236-5091

/s/ Ralph Getchell
Chief, Division of Technical Services
Aviation Management Directorate
National Business Center
U.S. Department of the Interior

/s/ Ron Hanks
Branch Chief, Aviation Safety Management Systems
Fire and Aviation Management
U.S. Forest Service
U.S. Department of Agriculture

NOTES

2015 NATIONAL INTERAGENCY AVIATION FREQUENCY GUIDE